


Torso Vest

Measure the child and choose the correct size




Provides a firm and flexible hold against the chest. It aims to prevent the child from falling forward.

	XS	S	M	L	XL	XXL
Shoulder (S) to Pelvis (P)	200 - 270 mm	270 - 320 mm	320 - 405 mm	405 - 470 mm	470 - 520 mm	520 - 600 mm

Cross Vest

Measure the child and choose the correct size




Provides a firm and flexible hold against the front and sides of the trunk. It aims to prevent the child from falling forward or sideways.

	XS	S	M	L	XL
Shoulder (S) to Pelvis (P)	200 - 315 mm	260 - 345 mm	345 - 450 mm	450 - 530 mm	530 - 620 mm

Y-hip belt

Measure the child and choose the correct size





Provides a pull down and/or back to maintain the position of the thighs and pelvis against the seat and backrest. It aims to prevent the child from changing the position of the pelvis and from sliding forward in the seat.

	XS	S	M	L	XL
Hip (H) to hip (H)	170 - 320 mm	210 - 350 mm	250 - 410 mm	320 - 440 mm	410 - 520 mm

Pelvis belt

Measure the child and choose the correct size




The fabric cover the area from the top of the pelvis to the seat and provides a backward pull on the pelvis. This aims to prevent the child from sliding forward and out of the seat. The pelvis belt is suitable for smaller children.

	XS	S	M
Hip (H) to hip (H)	160 - 200 mm	200 - 240 mm	240 - 280 mm

Ankle straps

Measure the child and choose the correct size



Limit movement of the feet and legs, preventing unwanted movements due to impairments in muscle tone or movement functions.

	XS	M	XL
Circumference (C)	160 - 230 mm	230 - 310 mm	290 - 380 mm

R82 Vests and belts

Measurement guide